

# Do More with John Deere Attachments



## 1 Hood Guard

Add more protection from dust and debris during rugged conditions or loader work.

**BW16009** – 5085E, 5085M, 5100M, 5115M Series Tractors

## 2 PowerReverser Modulation Control

Controls how quickly the transmission shuttle-shifts from forward to reverse. Allows for smooth, easy transition during operation in varying conditions.

**LVB25727** – 5E, 5M, 5EN, 5MH

## 3 Rear Fender Extension Kit

Rear fenders are designed to provide optimum mud control by increasing the coverage of the rear tires in all directions.

**LVB25714** – 5E, 5M, 5MH, 5MH Hi-Crop

## 4 Vandal Protection – Door Locks with Custom Keys

Keep your tractor locked up and protected. Features a separate key than the tractor's ignition key.

**AL71345** – 5E and 5M Series Cab Tractors

## 5 Toolbox

Enjoy a convenient location to store your tools on your cab or open station tractor.

**LVB24951** – 5E and 5M Series Tractors

# Do More with John Deere Attachments



## 1 Replaceable Cutting Edge

Effectively extend the life of your bucket with a replaceable cutting edge.

- BW15819** – 1,680 mm (66 in)
- BW14763** – 1,850 mm (73 in)
- BW14267** – 2,150 mm (85 in)
- BW13910** – 2,300 mm (91 in)
- BW14269** – 2,450 mm (96 in)

## 2 Hood Guard

Protect your tractor's grill and radiator from brush and workplace hazards.

- BW15219** – 3020/4020 Series Utility Tractors
- BW12980** – 30-55 Series Row Crop Tractors
- BW15892** – 6M and 6R Series Tractors
- BW15800** – 6D Series Tractors
- BW15922** – 7R Series Tractors
- BW15907** – 8R and 8030 Series Tractors

## 3 Ballast Box

Get greater tractor stability with additional ballast.

- BW15073** – Category 1 Hitch
- BW15852** – Category 2 and 3 Hitch

## 4 Digging Teeth

Add More versatility by applying digging teeth to heavy-duty buckets. The result is easier digging in hard ground.

- BW15227** – 1,550 mm (61 in)
- BW15228** – 1,850 mm (73 in)
- BW15763** – Heavy-Duty Bucket

## 5 5-Tine Grapple

Add a five-tine grapple for increased loader durability and load-carrying capacity.


- BW16161** – H Series Loaders

## 6 Return to Position (RTP) Elect Self-Leveling (ESL) Wiring Harness

The Return-To-Position (RTP) option for 6R Tractors and H340, H360, and H380 Loaders provides superior productivity and repeatability during material handling operations. An industry exclusive, RTP allows the operator to store two boom positions and two bucket positions through the use of sensors, the tractor's CommandCenter™, and controller.

- BL15219** – 6R Series Tractors Equipped with H Series Loaders

# Do More with John Deere Attachments



## 1 Cold Weather Starting Package – 110V

This package is recommended for tractors frequently started at or below -6°C (21.2°F).

AL205918 – 6M Series

## 2 Power Strip with 6 Outlets

An electrical power strip can be installed on tractors not equipped, providing six additional outlets for powering monitors or other electrical equipment.

AL174215 – 6M Series Cab

## 3 Instructional Seat

The placement of the instructional seat allows a trainee to properly observe tractor operation and diagnostics without impeding the tractor operator.

AL173569 – 6M Series Cab

## 4 Beacon Light, LH

The rotary beacon light is installed to meet requirements in commercial or governmental applications. The rotating, high-intensity light rests securely within an amber-colored safety lens.

AL111705 – 6M Series Cab

## 5 Fuel Tank Bottom Guard

These guards protect the fuel tank against any ground debris, rocks, or stubble when operating in rough terrain.

AL204819 – 6M Series Cab