


Do More with John Deere Attachments



1 Hood Guard

Hood Guards on H180 loaders can be ordered for a tractor without ordering a loader.

BW16459 – Standard on H180 Loaders
BW16155 – Deluxe on H180 Loaders

2 Backup Alarm

An alarm sounds whenever the transmission is placed in reverse. The alarm provides a high level of warning that the tractor is changing direction.

BLV10358 – 4M and 4R Series Tractors

3 Canopy and Canopy Mounting Kit

The canopy attaches to the rollover protective structure (ROPS) to protect the operator from inclement weather.
Open Station Tractors ONLY

LVB25334 (Canopy)
4M and 4R Open Series Tractors

LVB25332(Canopy Mounting Kit)
4M and 4R Open Series Tractors

4 Vertical Exhaust Kit

For applications that require a high exhaust system, over the head of the operator, a vertical exhaust kit is available. This kit is ideal for use around sensitive vegetation to direct exhaust up and away from plants.
Cab and OS Models

BLV10389 – 4044M/R Series Tractors
BLV10390 – 4052M/R Series Tractors
4066M/R Series Tractors

5 Forward Lighting Kit

The forward-lighting kit provides extra visibility when working in dark conditions.

LVB25546 – 4M and 4R Open Series Tractors